

Insert both push pins through holes, and turn over onto a flat surface as shown; With a soft mallet, gently tap the kickers onto the pins until snug.

