Spinner Display •Assembly Instructions




- 1. Join (4) slotted side panels to the backs of each adjoining panel, tightening all four fasteners on each panel with a Phillips screwdriver. HAND TIGHTEN ONLY, DO NOT OVERTIGHTEN!
- 2. With base/platform assembly right side up on the floor, place the assembled slotted panels onto the base, aligning the four pins to the receiving fasteners on the platform. Tighten all four platform fasteners.
- 3. See reverse side for header assembly, if applicable. Place assembled cap or header into the hole created by the four panels on top. Secure in place through the panels with the provided push pins (x4).





Header assembly (if applicable)



- 1. Place two upright parts (B) onto base (A) screws and slide until snug; gently tap with a soft mallet until centered and locked in place.
- 2. Slide top part (C) onto upright parts (A) and gently tap with a soft mallet until centered and locked in place.
- 3. Insert both signs by inserting one end in an upright slot, then slightly flex sign to insert in opposite ends.

